Days Countdown Timer

SR-HM200A

Life

·

Has all changed

Product Features:

1. Long Period of time setup: up to 1,999 days.
2. Back light function. Press any button to start the backlit. (The back light will be extinguished automatically if no operation is done for 5 seconds.)
3. Display Ending Time & Date, Starting Time & Date and Time Interval (between starting time and ending time) simultaneously.
4. Programmable Alarm Clock: ON/OFF.
5. Factory settings will be restored once the batteries are removed.
6. Display will show error when countdown time exceeds 20000 days.
7. Timer will count up automatically when starting time & date is after ending time & date.
8. Switchable 12/24 Hours.
9. Automatically calculated countdown time.

Product Specifications:

Batteries Required	AAA x 2
Product Color	Black/White
Housing Material	ABS
LCD Size	35 x 65 MM
Product Weight	145g

OPERATION INSTRUCTIONS

Set Your Ending Time & Date

1. Press and Hold **"Target"** button until the last 2 digits of YEAR start flashing, Press "UP/DOWN" button to adjust your "YEAR".
2. Press **"Target"** button, the digits of "MONTH" "DAY" "HOUR" "MINUTE" and "SECOND" will flash separately, Press "UP/DOWN" button to adjust your "MONTH" "DAY" "HOUR" "MINUTE" and "SECOND" separately.
3. Once your get your desired ending Time & Date, release the button, you are done.

Set Your Starting(Current) Time & Date



1. Press and Hold **"Current"** button until the last 2 digits of "YEAR" start flashing, Press "UP/DOWN" button to adjust your "YEAR".
2. Press **"Current"** button, the digits of "MONTH" "DAY" "HOUR" "MINUTE" and "SECOND" will flash separately. Press "UP/DOWN" button to adjust your "MONTH" "DAY" "HOUR" "MINUTE" and "SECOND" separately.
3. Once your get your desired Starting Time & Date, release the button, you are done.



Set Alarm Clock

1. Press and Hold the **"Alarm"** button until alarm time (Hours) starts flashing, press "UP/DOWN" button to increase/decrease the Hours.
2. Press **"Alarm"** button **twice** to set the "MINUTE" and Press **"Alarm"** button **3 times** to set your "SECOND".
3. **Once You finish the setting with no digit flashing, You can press "DOWN" button to turn off the alarm clock ("OFF" icon will show on the screen).**

TIP:

The Alarm Clock time and ending Time & Date will Alternate display every 10 Seconds.

When Alarm Clock is turned off, the alarm clock time will not show on the LCD screen.

Others

1. **12/24 Button:** A switch button between 12 hours format and 24 hours format.
2. **S/S Button:** A start / Pause button. To Pause the Clock will not affect the actual count down/up time.

Ending Time and Date



Countdown Time

Starting(Current) Time and Date

Product Constructions:

Detachable Design



Unit body



DIY Card



DIY Card fixing frame

Product Size:

Unit: MM





① LCD Screen
② UP
③ Down
④ Target: Set your Ending time and date
⑤ Current: Set Your Current(Starting) time and date
⑥ Alarm: Set Alarm Clock
⑦ S/S: Start / Pause the timer.
⑧ 12/24H Switch betwteen 12H format and 24H format
⑨ Battery Cover
⑩ Buzzer

CE RoHS
MADE IN CHINA



Back side

技术要求：

1.说明书要求：248X125MM,正反面印刷;(彩色印刷)

2.印刷材质：70克双胶纸;

3.说明书内容要求清晰，并且能通过相应的检测。

				Runleader® 宁波江北瑞利特电子有限公司				
标记	处数	签名	日期					
设 计 变 更				名称	RL-HM200A 中性说明书	图号	RLT-HM200A-Y-002	
制图			2018-07-05			版次	V1.0	
审核				材料	70g双胶纸	件数	1	图法
批准						重量		
						比例	1：1	